



CABINET PARTS

For Models: ED2VHGXM10, ED2VHGXM10, ED2VHGXM10, ED2VHGXM10


(White)

(Biscuit)

(Black)

(Stainless-VCN)

REFRIGERATOR



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: ED2VHGXMQ10, ED2VHGXT10, ED2VHGXM10, ED2VHGXML10

(White) (Biscuit) (Black) (Stainless-VCM)

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------


LITERATURE PARTS

1	LIT2188771	Use & Care Guide
	LIT2255377	Service & Wiring Sheet
	LIT2261698	Energy Guide
	LIT628370	Modular Ice Maker Service Sheet
2	2174748	Front Roller (2)
3	3400517	Screw
4	2196236	Roller (Rear) (2)
5	489427	Screw
6	2155013	Clip, Grille
7	489478	Screw
8	2209697	Shim
9	2203770	Hinge Top, FC
10	2203771	Hinge Top, RC
11	8281227	Screw
12		Hinge Cover, FC
	2203407W	White
	2203407T	Biscuit
	2203407B	Black
13	2217075	Hinge Bottom (2)
14		Filler, Wrapper
	2196094	White
	2196150	Biscuit
	2196097	Black
15		Grille
	2198467W	White
	2198467T	Biscuit
	2198467B	Black
16	489497	Screw
17	489464	Screw
18	940139	Drain Fitting
19	1108438	Extension Tube
20	1108439	Clip, Drain Tube
21	2188736	Cover, Unit
22		Hinge Cover, RC
	2203408W	White
	2203408T	Biscuit
	2203408B	Black
23	549193	Clamp, Service Cord
24	489084	Screw
25	2155311	Door Closer, Lower Cam (2)
26	489483	Screw
27		Cabinet (Not a Serviceable Part)
28	2186443	Housing, Water
29	2255518	Filter, Water
30		Cap, Water Filter
	2186494W	White
	2186494T	Biscuit
	2186494B	Black
31	489500	Screw
32	3400113	Screw
33	3400103	Screw
34	8281149	Screw
35	2203098	Plate, Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR LINER PARTS

For Models: ED2VHGXMQ10, ED2VHGXTM10, ED2VHGXMB10, ED2VHGXML10
(White) (Biscuit) (Black) (Stainless-VCM)



Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2194744	Escutcheon, Meat Pan Control
3	2182757	Slide, Meat Pan Control
4	2257741	Louver
5	2256037	Wire Harness, Dual Crisper
8	2196485	Stud Assembly (2)
9	3400894	Screw
11	489290	Screw (2)
12	2256035	Bracket, Dual Crisper Light
13	2206270	Shelf Ladder
14	487539	Screw
21	2152019	Air Diffuser Cover
22	1123919	Bracket Retainer
24	2209753	Air Diffuser Assembly
26	2150331	Cover, Conduit
27	486298	Screw
29	2162085	Socket
31	2256126	Reservoir
33	527949	Light Bulb
34	2209769	Light Lens
35	2172840	Strap
37	488280	Screw (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


For Models: ED2VHGXMQ10, ED2VHGXMT10, ED2VHGXMB10, ED2VHGXML10
(White) (Biscuit) (Black) (Stainless-VCM)

Illus. No.	Part No.	DESCRIPTION
1	2188695	Shelf Assembly, Cantilever (2)
2	2209698	Cover, Crisper
3	2179259	Glass, Cover
4	2179350	Deflector
5	2217039	Cover, Meat Pan
6	2188652	Crisper Pan
7	2188654	Meat Pan
9	2179343	Front, Cripser
10	2179342	Slide, Humidity Control
13	2174150	Glass, Cover
19	2255592	Trim, Handle
20	2255593	Trim, Handle



FREEZER LINER PARTS

For Models: ED2VHGXMQ10, ED2VHGXT10, ED2VHGXMB10, ED2VHGXML10
(White) (Biscuit) (Black) (Stainless-VCM)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS


For Models: ED2VHGXM10, ED2VHGXM10, ED2VHGXM10, ED2VHGXM10
(White) (Biscuit) (Black) (Stainless-VCM)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	1115380	Slide, Ice Door
3	2171712	Door, Ice Compartment
4	8281158	Screw
5	489478	Screw
6	842534	Clip, Air Duct (2)
7	2196206	Support, Stud (4)
9	3400893	Screw
10	2176134	Grommet
11	2216111	Freezer Bin
17		Slide, Basket
	2261449	Right Side
	2261448	Left Side
18	486298	Screw
19	1115373	Switch, Rocker Arm
20	2196483	Stud Assembly
22	3400893	Screw
25	527949	Light Bulb
26	2162085	Light Socket
27	2196207	Stud, Rear
28		Slide, Container
	1119237	Left Side
	1119293	Right Side
29	489100	Screw
31	2174265	Shelf (2)
	2174249	Shelf (1)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND ICE CONTAINER PARTS

For Models: ED2VHGXMQ10, ED2VHGXMT10, ED2VHGXMB10, ED2VHGXML10
(White) (Biscuit) (Black) (Stainless-VCM)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND ICE CONTAINER PARTS

For Models: ED2VHGXMQ10, ED2VHGXMT10, ED2VHGXMB10, ED2VHGXML10


(White) (Biscuit) (Black) (Stainless-VCN)

Illus. No.	Part No.	DESCRIPTION
1	2183728	Bracket, Motor
2	2188385	Motor, Dispenser
3	2152713	Solenoid Assembly
4	2149100	Gudie, Solenoid
6	1115374	Clip, Wiring
7	2206501	Wiring Assembly, Ice Dispenser
8	489399	Screw
9	2205716	Coupling, Motor
10	489478	Screw
11	2162085	Socket, Light
14	2196089	Ice Container
18	1119005	Spacer, Step (3)
19	1119007	Spacer, Flat (2)
20	1119006	Blade, Rotary
21	1119012	Blade, Rotary
22	1119013	Blade, Rotary
23	489235	Washer, Plain
24	1119009	Blade, Fixed (2)
25	2157405	Block, Blade
26	489229	Roll Pin
27	2196295	Auger
28	2209781	Drum
30	2171682	Floating Baffle
31	1119018	Nut, Bearing
32	2155231	Control Arm
33	1119020	Spring, Return
34	1119021	Retainer Clip, Rod
35	488886	Screw
37	2180348	Housing, Crusher
38	1119017	Deflector, Ice
39	489234	Washer, Plain
40	489236	Retainer Ring
44	2171709	Front Cover, Ice Container
45	527949	Light Bulb
46	2171706	Light Lens, Dispenser

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

For Models: ED2VHGXMQ10, ED2VHGXMT10, ED2VHGXMB10, ED2VHGXML10
(White) (Biscuit) (Black) (Stainless-VCM)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS


For Models: ED2VHGXM10, ED2VHGXM10, ED2VHGXM10, ED2VHGXM10
(White) (Biscuit) (Black) (Stainless-VCM)

Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door (Includes Item 6)
	2206716W	White
	2206716T	Biscuit
	2206716B	Black
	2206716L	Stainless-VCM
2	2256101	Door, Compartment
3	489491	Screw
4	2187172	Door Bin (3)
5		Extension, Top
	2194971W	White
	2194971T	Biscuit
	2194971B	Black
6		Door Gasket, Magnetic
	2221300	Mist Beige
	2221311	Black
7		Handle, Center
	2186649W	White
	2186649T	Biscuit
	2186649B	Black
8	2177962	Trivet
9	2195327	Clip (4)
10		Extension, Bottom
	2194969W	White
	2194969T	Biscuit
	2194969B	Black
11	2182178	Door Closer, Upper Cam
12	489420	Screw
13		Bracket, Door Stop
	2206629	Chrome
	2206629B	Black
14	2262218	Nameplate
16	2182180	Thimble, Top
19	3400852	Screw
24	3400012	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS

For Models: ED2VHGXM10, ED2VHGXML10
(White) (Biscuit) (Black) (Stainless-VCM)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS


For Models: ED2VHGXMQ10, ED2VHGXT10, ED2VHGXTB10, ED2VHGXTL10
(White) (Biscuit) (Black) (Stainless-VCM)

Illus. No.	Part No.	DESCRIPTION
1		Freezer Door (Includes Item 8 And Dispenser Front Parts)
	2255770W	White
	2255770T	Biscuit
	2255770B	Black
	2255770L	Stainless-VCM
2		Handle, Center
	2186649W	White
	2186649T	Biscuit
	2186649B	Black
3	2195327	Clip (4)
4	489491	Screw
5		Extension, Bottom
	2194969W	White
	2194969T	Biscuit
	2194969B	Black
6	2195919	Trim, Shelf (4)
7	3400012	Screw
8		Door Gasket, Magnetic
	2221301	Mist Beige
	2221312	Black
9	2209680	Trim, Door Shelf
10	488500	Screw
11	2206602	Wire Harness
12	2182179	Door Closer, Upper Cam
13	489420	Screw
14		Bracket, Door Stop
	2206629	Chrome
	2206629B	Black
15	2195916	Endcap (4)
16	2195917	Endcap (4)
17	2182181	Thimble, Top
18		Extension, Top
	2194971W	White
	2194971T	Biscuit
	2194971B	Black
22	3400852	Screw
23	2154473	Connector

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISPENSER FRONT PARTS

For Models: ED2VHGXMQ10, ED2VHGXMT10, ED2VHGXMB10, ED2VHGXML10
(White) (Biscuit) (Black) (Stainless-VCM)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISPENSER FRONT PARTS


For Models: ED2VHGXM10, ED2VHGXM10, ED2VHGXM10, ED2VHGXM10
(White) (Biscuit) (Black) (Stainless-VCN)

Illus. No.	Part No.	DESCRIPTION
1		Housing, Dispenser (Not Serviced)
2	3196537	Screw
3	2194719	Retainer, Levers
4	2256199	Spring, Torsion
5	2196195	Pin
6	2180352	Door, Ice
7	2206423	Door Mechanism Assembly
8	2205686	Mechanism Delay
9		Grille, Overflow
	2206671W	White
	2206671T	Biscuit
	2206671B	Black
10	2209718	Water Fitting Assembly (Includes Water Tube)
11		Lever, Ice Dispenser
	2255431W	White
	2255431T	Biscuit
	2255431B	Black
12	2180224	Guide, Ice
13	2180200	Lamp Holder
14	2162361	Switch
15	2183771	Bracket, Control
16	3406124	Bulb, Light
17		Lever, Water Dispenser
	2255432W	White
	2255432T	Biscuit
	2255432B	Black
18		Switch Assembly (Not Available, Order #23)
19		Overlay, Front Cover (Not Available, Order #23)
20	2187409	Wire Assembly
21		Front Cover, Housing (Not Available, Order #23)
22	489000	Screw
23		Front Cover Assembly (Includes Items 18, 19, 20 & 21)
	2255768W	White
	2255768T	Biscuit
	2255768B	Black
24	625834	Spacer, Switch (2)
25	2195051	Strain Relief
26	987121	Shield, Ice Door

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: ED2VHGXMQ10, ED2VHGXT10, ED2VHGXTB10, ED2VHGXTL10
(White) (Biscuit) (Black) (Stainless-VCM)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: ED2VHGXM10, ED2VHGXM10, ED2VHGXM10, ED2VHGXM10

(White)

(Biscuit)

(Black)

(Stainless-VCN)

Illus. No.	Part No.	DESCRIPTION
1	486692	Speed Nut
2	2190685	Fan, Blade
3	2204484	Condenser Assembly
4	489464	Screw
5	2208280	Clip, Wire
6	8281160	Screw
7	2216997	Insert, Bracket
8	2161302	Sleeve
9	2183454	Relay (Service Only)
10	2216914	Clip, Condenser
11	2255798	Tube, Condenser To Heat Loop
12	4387731	Cover (Service Only)
13	2187145	Overload (Service Only)
14	4387765	Wire, Capacitor (Service Only)
15	2223314	Clip, Retaining
16	2205764	Tube Suction
17		Capacitor
	999532	Production
	1118576	Service
18	2220474	Start Device, Combination (Start Relay and Overload) For Production Compressor Only

Illus. No.	Part No.	DESCRIPTION
21	489478	Screw
22	2164518	Evaporator
23	2161324	Clamp
24	2206005	Fan, Motor
25	1105523	Tray, Evaporator
26	2256149	Heat Shield
27		Drier
	2199167	Production
	4387019	Service
28	2212191	Compressor (Includes Items 9, 12, 13, 14, 17 & 27) (Also Order 876765 Tube Kit)
30	2160501	Unit Mounting Frame
31	2187783	Unit, Harness
32	2181929	Fan, Motor Bracket
33	2188174	Heater, Defrost
34	2161330	Clip
35	2196155	Bi-Metal, Defrost
37	489373	Screw
39		Grommet (4)
	1100826	Production
	4387558	Service
40	489340	Screw
41	2196202	Air Baffle
42	2155547	Clip, Heat Shield
43	2182057	Unit Cover, Bottom
44	489396	Clip
48	2149718	Unit Mounting Rail
49	8281232	Screw
50	2186496	Guard, Fan

Illus. No.	Part No.	DESCRIPTION
52	2205813	Strap
53	489427	Screw
55	488649	Screw
63	2209709	Connector, Water Tube

Following Parts Not Illustrated and Optional Parts Not Included

978025	Valve, Access (1/4")
978026	Valve, Access (5/16")
978027	Valve, Access (3/8")
978028	Valve, Access (1/2")
978029	Valve, Access (5/8")
978030	Valve, Access (3/4")
876764	Valve, Access (3/16")

REFRIGERANT CHARGE

5.0 oz.
(R-134A)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

AIR FLOW PARTS


For Models: ED2VHGXM10, ED2VHGXM20, ED2VHGXM30, ED2VHGXM40

(White)

(Biscuit)

(Black)

(Stainless-VCM)




Illus. No.	Part No.	DESCRIPTION
1	2182119	Fan Scroll
2	2155590	Retainer, Fan Motor
3	2161231	Air Scoop
5	2203591	Air Duct Freezer
6	2149544	Diffuser Air Duct
7	2188303	Fan Motor
8	2169142	Fan Blade
10	2176759	Fan Grommet (2)
11	2182146	Duct, Ice-maker
12	2206504	Harness, Fan Evaporator, And Heater, Bi-Metal
13	2155788	Gasket Cover
14	2172840	Wire Tie
16	2203875	Gasket
17	2203840	Cover, Evaporator
18	489355	Screw
21	489478	Screw
22	2203595	Support, R.S
23	2203596	Support, L.S

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PARTS

For Models: ED2VHGXM10, ED2VHGXM10, ED2VHGXM10, ED2VHGXM10
(White) (Biscuit) (Black) (Stainless-VCM)



Illus. No.	Part No.	DESCRIPTION
1	2200136	Control Box
2	1110629	Mounting Bracket
3	3196537	Screw (4)
4	2149705	Light Switch
6	2188159	Adaptive Defrost Control
7	489398	Screw (2)
8	940014	Hole Plug
9	2198202	Thermostat Assembly
10	487869	Screw


Illus. No.	Part No.	DESCRIPTION
11	2182195	Cam Assembly
12	1110560	Bearing Body
14	2196062	Clip, Damper Control
15	1110559	Pivot Arm
16	627068	Screw
17	2162085	Light Socket
18	2196001	Thermostat, Barrier
19	527949	Light Bulb

Illus. No.	Part No.	DESCRIPTION
20	2206511	Control Box Harness
21	1115374	Clip, Wiring
22	1115375	Clip, Wiring
23	1123960	Connecting Rod
24	489285	Fastener, Push-On
25	2255597	Escutcheon, Control Box
26	2182111	Thermostat knob
27	2197871	Knob, Air Control
29	489203	Spring Washer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: ED2VHGXMQ10, ED2VHGXT10, ED2VHGXMB10, ED2VHGXML10
(White) (Biscuit) (Black) (Stainless-VCM)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: ED2VHGXM10, ED2VHGXM10, ED2VHGXM10, ED2VHGXM10
(White) (Biscuit) (Black) (Stainless-VCM)

Illus. No.	Part No.	DESCRIPTION
1	489084	Screw
2	2209774	Chute, Water
3	2255012	Tube, Filter Outlet
4	2188744	Tube, Filter Inlet
5	628379	Clip, Fuse
7	2181943	Tube, Water
9	489478	Screw
10	2188708	Filter Valve Asm
14	2208136	Tube Clip
18	2174155	Cover
19	488649	Screw
20	628228	Mold & Heater Assembly (Also Order 542638
22	628356	Cup, Water Fill
23	627843	Ejector
24	2182124	Ice Striper
25	2194712	Support
26	627796	Retainer, Thermostat
27	628397	Thermostat (Also Order 542369 Cement Alumilastic)
28	8533917	Screw
30	489276	Screw
31	2209675	Shut Off Arm
33	628320	Bracket
35	626653	Module Assembly (Includes Items 37 and 38)
36	488208	Screw
37	627811	Motor
38	489136	Screw
100	4317943	Complete Icemaker Assembly

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

PARTS NOT ILLUSTRATED

For Models: ED2VHGXM10, ED2VHGXM10, ED2VHGXM10, ED2VHGXM10
(White) (Biscuit) (Black) (Stainless-VCN)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
Parts Not Illustrated and Optional Parts (Not Included)			Miscellaneous			Refinishing Material		
Customer Touch-Up Material								
	*350942	Primer, White (12 Oz. Spray Can)		212643	Sealer, Gum (4 Feet)		799340	Enamel, Black (1 Qt. Uncut)
	*350939	Enamel, Black (12 Oz. Spray Can)		479502	Tape, Vinyl (3/4 x 108")		799344	Enamel, White (1 Qt. Uncut)
	*350930	Enamel, White (12 Oz. Spray Can)		876370	Kit, Insulation (2 Pcs. x 3" x 24" x 48")		978883	Enamel, Almond (1 Qt. Uncut)
	*350956	Enamel, Almond (12 Oz. Spray Can)		876305	Kit, Insulation (14 Pcs. x 3" x 24" x 48")		4392900	Enamel, Biscuit (1 Qt. Uncut)
	*4392901	Enamel, Biscuit (12 Oz. Spray Can)		978941	Insulation, Fiberglass (63-1/2" x 35-1/2" X 2-5/8)	TORX SCREW WRENCH		
	72017	Brush Touch-Up Kit (White)		876029	Kit, Foam Slab (30" x 32-1/2" x 1-1/2")		1117510	Torx Key
	72107	Brush Touch-Up Kit (Almond)		505587	Sealer, Mastic (1 Qt.)			
	72032	Brush Touch-Up Kit (Black)		503695	Cork, Sealer (1/4 Pound)			
	4392899	Brush Touch-Up Kit (Biscuit)		511873	Touch-Up, White Porcelain (2 Oz.)			
				542638	Grease, Silicone (1/2 Oz.)			
				542639	Cement, Alumilastic (1-1/4 Oz.)			
				606755	Bag, Insulation (36-5/8" x 46")			
				799833	Kit, Evaporator Repair (Aluminum Epoxy)			
				833938	Kit, Terminal Connector			
				2209779	Ice Container Assembly			

***Important:** The spray paint is not to be used where the paint may make contact with the door gaskets.

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST